



Antennas





≥ 1 m

≥ 0,5 m

*optional accessories:
ADP UHF (470 - 1075 MHz)
AD 1800 (1400 - 2400 MHz)


Instruction Manual


Download on the App Store


GET IT ON Google Play


Download on the App Store


GET IT ON Google Play

Sennheiser Documentation App

or online at
www.sennheiser.com/download
EW-D_

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Printed in Germany
Publ. 02/21, 583962/A02




Evolution Wireless Digital

EW-D EM
EW-D SK
EW-D SKM-S


Quick Guide
Kurzanleitung
Guide rapide
Guida rapida
Guía de inicio rápido
Guia rápido
Beknopte handleiding
Krótka instrukcja obsługi
Snabbguide

Kort vejledning
Pikaohje
Γρήγορος οδηγός
Kısa Kılavuz
Краткая инструкция
快速指南
퀵 가이드

Audio Out




Power supply



EW-D Smart Assist

The EW-D Smart Assist app simplifies your workflow







Download on the App Store



GET IT ON Google Play



In the box




Battery



2 AA batteries (included)

*optional: BA 70 rechargeable battery


SKM-S




2 AA batteries (included)


*optional: BA 70 rechargeable battery


EW-D EM






On/Off


EM


SKM-S


SK

Off -> On


short

EM/SK/SKM-S

on

On -> Off


long

EM/SK/SKM-S

off

Identify/Battery check

On -> Identify/Check


short


SK/SKM-S

Identify/Check

SKM-S



SK




LINK LED SK/SKM-S

≤ 100 %


≤ 60 %

≤ 20 %

Display of synced EM



EW-D SKM-S



EW-D SK

